

Core Analysis Pressure Regulator


NANO-FLOWS FOR OIL AND GAS RESERVOIR EXPLORATION



The Oil and Gas Industry has special requirements for back pressure regulators for conducting core analysis of rock samples (core plugs). In conventional core analysis, samples are analyzed to determine hydrocarbon content that can be evolved at different temperatures and at differing time periods whilst maintaining a pressure consistent with the reservoir's overburden. In core flooding analysis, the rock's permeability to gas, oil, and brine is measured.

Back pressure regulators are a key component of many core analysis applications. While some core analysis experiments use inert gas flow through the sample to transport the hydrocarbons, many other core analysis applications require that the sample reactor maintain a constant pressure under no-flow conditions. For example, a rock sample may evolve no gases or hydrocarbons during the early part of a temperature ramp, but later evolve significant flows of condensable hydrocarbon gases as the temperature ramps up.

Core Flooding Schematic



A back pressure valve is often located downstream of the core sample reactor to maintain the “overburden” pressure. The ideal BPR can hold the reactor pressure at a very stable pressure even as the flow rates vary from true zero flow up to high flow rates (typically tens or hundreds of ml/min). Unfortunately, most existing back pressure regulators either cannot hold stable pressure under zero-flow conditions, or they cannot provide stable inlet pressures as flow is initiated and increased.

Slim-Tube Testing

Another key use of Equilibar back pressure regulators in the arena of reservoir testing is slim-tube testing. As explained in [Schlumberger's Glossary](#), this test is used to determine the minimum

miscibility pressure (MMP) or minimum miscibility concentration (MMC) of injection solvents in selected reservoir oil. Fluids are injected into a long coil of tubing packed with sand; the back pressure regulator is key to maintaining the coil pressure at the specified values. The high precision and two-phase tolerance of the Equilibar can improve the performance of the slim-tube test apparatus. An Equilibar BPR can be used at pressures up to 10,000 psig.

Equilibar's Zero-Flow Back Pressure Regulator


The Equilibar ZF Series are specifically designed to address the challenging requirements of the reservoir testing industry. The ZF ("Zero Flow") Series regulators hold inlet pressures stable within about 0.5% from true bubble-free zero flow, up to the range of 1 liter/minute.

The ZF1 regulator has been proven to address critically challenging and previously impossible applications in core analysis and other research applications requiring micro-flow pressure control. A soft-seal elastomeric o-ring is used to accomplish the ultra-tight closure in the ZF. Viton is standard, with FFKP also in stock. The ZF is available SS316 (standard) or other alloys such as HastelloyC. Although standard fittings are NPT, other options available include low dead-volume styleHPLC (Valco-style) fittings or Autoclave Engineer style.

CORE ANALYSIS PRESSURE REGULATOR



- **Very wide dynamic flow range**
- **True zero flow shut off**
- **High pressure capability (10,000 psi)**
- **High temperature capability (450 C)**
- **Available in 316SS, Hastelloy and Zirconium**



Web : www.pctflow.com

Email : sales@pctflow.com

Tel : 01953 609930

